
Product Quality Manual

of Aibeli® Square tube Handle








XINYE MACHINERY Manufacturing Corporation

Concentration.Professional.Devotion
















Step1:sanding 2 times by sand belt



Step2:brushing surface by 320# Wire wheel



Brushed 120 meshes or 180meshes (Common quality in market)




Brushed 320 meshes (Xinye's quality)












Step1:sanding 4 times by sand belt, from coarse to fine,
2times coarse sand
2times fine sand

Step2:brushing surface by hemp wheel







Step3:brushing surface by cloth wheel




















































Product Quality Manual

of Aibeli® Square tube Handle

Rev. 0.7







XINYE MACHINERY

Manufacturing Corporation

Concentration.Professional.Devotion